Special Front Panel Button Functions

Special operations which are useful for managing your SC7700-RISOGRAPH printing system can be realized by turning on the SC7700 while holding down the front panel buttons.

The respective front panel buttons provide you with the special operations described below. To start these operations, release the corresponding button(s) when a beep sounds approx. 30 seconds after the SC7700 is turned on.

[START] Button ..... Printing self test page

[Function] Button ..... Printing the settings and font sample pages



The RISOGRAPH's operation is interrupted between the pages. To print additional copies, press the start key on the RISOGRAPH control panel.
To print the next page, press the STOP button.

[Start] and [Stop] Button .. Initializing the SC7700 settings.